


Electronic Dish Dryer Instruction Manual

(Please read this manual carefully prior to initial use and retain it for future reference.)



COLENT MARKETING PHILIPPINES INC.

www.colentco.com

Berton's Place # 46 Sta. Rosa Street Barangay Manresa Quezon City Tel Nos.(632)442-3856;442-3866;448-7674;412-6155;413-9503 Email:sales_mktg@colentco.com/iwata@colentco.com

A CAUTION

- 1. Keep dish dryer out of reach of children.
- 2. Keep power cord away from liquids.
- 3. Discontinue using when error occurs.
- Do not use solvents on the unit.
- 5. Do not use accessories unless they are provided by IWATA.
- 6. Do not use tablewares on the unit with melting point below 90°C.

A NOTICE

- 1.Ensure that power supply is 220V~/60Hz.
- 2.Do not open the cover when the unit is operational to avoid burning your hands.

FUNCTIONALITY

- 1. Health: Sealed storage unit with antibacterial heating feature.
- 2.Convenience: Tablewares can be directly stored without wiping them dry. 3.Energy saving: Precise control with advanced microcomputer and low power of 0.25KWH possible for running a 280W ultra alternating thermal system.

SPECIFICATION

Product Model:	CM17DD-3
Product Name:	Electronic Dish Dryer
Rated Voltage/Power:	220V-280W
Unit Dimension (L*W*H):	420*306*530mm
Net Weight/Gross Weight:	6.2kg/8.1kg
Time Setting:	25-45mins

OPERATION

- 1. Close the cover after tablewares are put in place.
- 2. Press button, indicator will light up and flash. It will run in standard mode.



3. Press 🗑 button again, it will run in next mode as following:



Mode	Setting Time	Reference
STANDARD	35 mins	Normal 50% load
HALF LOAD	25 mins	In small quantity 11% - 49% load
FULL LOAD	45 mins	50% - 100% load
BLOWER	10 mins	Room temperature without heater drying

COMPONENTS

Photos are for reference only. This product does not include utensils.

