



Model: PRO – BLEND MAXX

COMMERCIAL BLENDER



Exclusively distributed by:

COLENT MARKETING PHILIPPINES, INC.

Berton's Place, #46 Sta. Rosa Street, Quezon City, Philippines 1115

Website: www.colentco.com

Landline: (632)442-3866 ; 412-6155 ; 413-8819 ; 442-3856 ; 448-7674

Mobile: 0923-5345681; 0917-3079188 ; 0920-9746874

Email: sales_mktg@colentco.com, iwata@colentco.com, iwata2@colentco.com

or iwata3@colentco.com

READ THIS MANUAL THOROUGHLY PRIOR TO INITIAL USE AND SAVE FOR FUTURE REFERENCE

SAFETY PRECAUTIONS

Check that the local voltage supply matches the rated voltage of product.

1. Do not allow the power cord and plug to come in contact with water or other liquids to avoid electric shock or fire.
2. Do not allow children and persons with reduced physical and mental abilities to operate the blender without any adult supervision.
3. Unplug the unit before changing accessories or cleaning and make sure the motor is turned off when removing the pitcher from the base.
4. The product and its power cord should be properly and safely stored to avoid accidents.
5. Do not use the appliance if power cable or plug is broken or defective.
Please contact the distributor/customer service for repairs.
6. Please position the blender on a desk or flat place when using.
7. Please do not use this blender under such situations: high temperature, near inflammable gas or an electric stove & etc.
8. Do not touch any part of the blade when unit is turned on.
9. The blades are very sharp. Please be careful when assembling or cleaning it to avoid injuries.
10. Do not use unauthorized attachment/s with the blender. The use of

attachments that are not recommended by the manufacturer can result in injury or damages and will void warranty on the unit.

11. Do not immerse the pitcher in water or other liquid when cleaning.

12. Make sure the pitcher is properly mounted to de-activate the safety switch.

PRODUCT SPECIFICATIONS



SPECIFICATIONS

| Item No.: | Rated Voltage | Frequency | Power | Capacity | Rated speed |
|----------------|---------------|-----------|-------|----------|-------------|
| PRO-BLEND MAXX | 220V-240V | 60HZ | 2000W | 2.0L | 28000RPM |

CONTROL PANNEL



1. Prior to initial use, check that all parts are complete and that the base is in good condition then pour 1000ml of water into the pitcher and let it run at mid speed for a minute to clean it. Throw the water afterwards.
2. Start with a slower speed and adjust accordingly while blending liquids to avoid spilling.
3. Use PULSE function when the mixture inside the pitcher is not blending.

WARNING: The blades are extremely sharp. Do not touch them.

OPERATING THE UNIT:

1. When power is on, make sure the speed control knob is at “MIN” position and function knob is at “0” position, then adjust the speed control knob from low to high in clockwise direction. The machine will stop when set at “MIN” position.
2. When power is on, make sure the speed control knob is at “MIN” position and function knob is at “0” position, adjust the speed control knob to the desired setting in clockwise direction. It will automatically start to work after 3 seconds. The machine will stop when set at “0” position anytime during the operation.
3. When power is on, the function knob does not activate when the speed control knob is working and vice-versa.
4. PULSE switch: When the ON/OFF switch is in the OFF position, flip the PULSE lever to activate the pulse function. The product will gradually accelerate to the highest speed within 3 seconds, and it will stop when you release it. When the ON/OFF switch is in the ON position, you can flip the PULSE lever to activate pulse function while the speed control knob is being used. The product will gradually accelerate to the highest speed within 3 seconds.