

Instruction Manual
Air Cooler
MODEL NO.:Aircool-Z21

Thank you for purchasing our evaporative air conditioner. Please read the instructions before initial use and save them for future reference.

TABLE OF CONTENTS

1. Warnings and personal safety
2. Important safety instructions
3. Technical information
4. Maintenance and cleaning
5. Technical specifications
6. Technical service

1. Warnings and personal safety


- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.
- Children shall not play with the appliance.
- Cleaning and user maintenance shall not be made by children without supervision.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- Ensure that the fan is switched off from the supply mains before removing the guard.
- Unplug the appliance during filling and cleaning.

2. Important safety instructions

- This product is for household and indoor use only.
- Connect the appliance to a single-phase AC supply of the voltage specified on the rating label.
- Always turn the product off and unplug it from the electrical outlet when not in use.
- Extreme caution is necessary when the appliance is used by or near children or the elderly.
- Do not run the cord under carpeting and do not cover the cord with rugs or anything similar. Arrange the cord away from busy areas where it will not be tripped over.

- Do not operate the appliance with a damaged cord or plug, or after it has been dropped or damaged in any manner.
- Use the appliance in a well-ventilated area. Keep this appliance at least 20cm away from walls to ensure the air intakes and exhaust openings do not get blocked.
- Do not insert fingers or any other objects into the grill to avoid a mechanical danger whilst in use.
- If you want to move the product whilst water is in the tank, unplug it and push it slowly and lightly on the side of the unit to avoid water spillage.
- Use this appliance on a flat and dry floor only.


3. Technical Information



A	Swing	B	OFF
C	Low	D	Middle
E	High	F	Cool

1. Insert the plug directly into a standard AC socket
2. Press the speed button to set the desired fan speed (LOW, MIDDLE, HIGH).
3. Press the swing button and the vertical blades will swing. Press the button again, stop swing. Manually adjust the horizontal louvers.

4. Cool button: Ensure there is enough water in the tank when using COOL function to avoid damaging the pump and always unplug the unit before adding water in the tank.



1. Air outlet	6. Stopper
2. Control panel	7. Ice pack(2 pcs.)
3. Wheels (4 pcs.)	8. Top cover
4. Air inlets and cooling pads	9. Upper water tray
5. Water tank	

- 1) Add enough water before using the COOL function. Press COOL function and water pump will start circulating water into the cooling pads. A full water tank may be used for around 6-8 hours. Press COOL function again to stop.
- 2) If you find that the air is still not cool enough, you can add additional ice blocks into the water tank directly by opening the water tank cover.

Description of Ice pack

There are a small number of ice crystal particles in the ice crystal pack. It is necessary to add proper amount of water (not exceeding the maximum water level) before it can be used. Put the ice crystal pack into the freezer and then put it into the water tank or top water tray when using.

4. Maintenance and cleaning

- Always remove the plug from the socket and all the fan blower to stop before cleaning it.
- Do not immerse the unit in water.
- Do not use any cleaning chemicals such as detergents and abrasives.
- Do not make all the interior get wet as this can create a hazard.
- Clean the external surfaces of the unit with a soft damp cloth.
- After extended periods of use, replace the water in the tank with fresh clean water at least once in a week.
- Remember to clean the dust proof bracket and water pad by unscrewing the dust-proof bracket and removing them.

It should be cleaned in a mild soapy solution and then left out to dry before replacing them.

- When the unit is not in use, make sure it is unplugged from the wall socket, water is drained thoroughly, and it is placed in its original box for storage until later use.
- In case of malfunction or doubt, do not try and repair the unit by yourself as it may result in a fire hazard or electric shock.

5. Technical specifications

Model NO.	Aircool-Z21
Rated voltage	220V 60Hz
Power	80W

6. TECHNICAL SERVICE

Dear Customers, for any doubt related to this product, you may contact our Customer Service. We are more than happy to help you.

Berton's Place #46 Sta. Rosa Street Barangay Manresa Quezon City
Tel Nos. 8442-3856; 8442-3866; 8282-5049, 8282-5098
Email: sales_mktg@colentco.com/iwata@colentco.com *Website: www.colentco.com