

Instruction Manual
Air Cooler
MODEL NO.:Aircool-Z22

Thank you for purchasing our evaporative air conditioner. Please read the instructions before initial use and save them for future reference.

TABLE OF CONTENTS

1. Warnings
2. Warnings about batteries
3. Technical informations
4. Instructions for use
5. Maintenance
6. Technical service

1. Warnings

ATTENTION: read this manual carefully as it contains important instructions for a safe installation, use and maintenance.

Important instructions to be kept for future reference.

This appliance may be used by children 8 years of age and older and people with reduced physical, sensory or mental capacities or with a lack of experience and knowledge if they are adequately supervised or have been instructed on the safe use of the appliance and are aware of the related dangers.

Children must not play with the appliance.

Cleaning and maintenance operations must not be performed by children without supervision.

If the power cable gets damaged, it has to be replaced only at a service centre approved by the manufacturer in order to prevent any risks.

- **Unplug the appliance during filling and cleaning.**

- Do not leave water in the tank when the appliance is not in use.

- Empty and clean the appliance before storage. Clean the appliance before next use.

Store and use the device only indoor or in any case protected from weathering such as rain, direct radiation of the sun and dust. The device is not designed for the external use or storage.

The cleaning and maintenance of the device MUST NOT be done by children without the supervision of an adult.

Before unplugging the device, switch it off, using the proper command on the control panel.

Place the device at a proper distance from the objects or surrounding walls making sure that its functioning will not cause accidental damages.

DO NOT use the device near gas stoves or open flames in general.

DO NOT use the device near curtains or textiles.

DO NOT hang the fan on the wall or ceiling unless this type of installation is provided and explained in this manual.

DO NOT cover the device during functioning.

DO NOT insert objects or body parts inside the protection grille of the fan.


DO NOT leave the device unsupervised for a long period when in operation.

2. WARNINGS ABOUT BATTERIES

1. **KEEP BATTERIES OUT OF THE REACH OF CHILDREN.** Swallowing can lead to chemical burns, perforation of soft tissue, and death. Severe burns can occur within 2 hours of ingestion. Seek medical attention immediately.
2. Do not allow children to replace batteries.
3. Always insert batteries correctly with regard to polarity (+ and -) marked on the battery and the equipment.
4. Do not short-circuit batteries.
5. Do not charge batteries.
6. Do not force discharge batteries.
7. Do not mix new and used batteries or batteries of different types or brands.
8. Exhausted batteries should be immediately removed from equipment and properly disposed of.
9. Do not subject batteries to heat.
10. Do not weld or solder directly to batteries.
11. Do not dismantle batteries.
12. Do not deform batteries.
13. Do not dispose of batteries in fire.
14. A lithium battery with a damaged container should not be exposed to water.
15. Do not encapsulate and/or modify batteries.
16. Store unused batteries in their original packaging away from metal objects. If already unpacked, do not mix old and new batteries.
17. Remove batteries from equipment if it is not to be used for an extended period of time unless it is for emergency purposes.

18. Clean the battery contacts and also those of the equipment prior to battery installation.
19. In case of leak from batteries, avoid any contact with it; in case of contact, wash the affected part with water and seek medical attention.

3. Technical information



1. Air outlet	6. Drain cap
2. Control panel	7. Ice box (2 pcs.)
3. Wheels (4 pcs.)	8. Remote control
4. Air inlets and cooling pads	9. Top cover
5. Water tank	10. Upper water tray

4. Instructions for use

Take out the product from the carton and insert the wheels by pushing them inside the 4 holes placed on the bottom of the product.


Fill the water tank:

- Open the cover (9);
- Fill the tank (5) from the upper water tray (10) with cold and clean demineralized water. Make sure that water level (5) on the tank is between "Min" minimum level and "Max" maximum level.
- Fill the ice pack with water and freeze it before using. Add frozen ice packs inside the upper tray to maximize cooling effect
- Close the cover (9).

ATTENTION!

- Make sure the product is unplugged from the mains before filling or refilling the water tank.
- Only use tap water in the water tank. Do not add any chemicals, oils or other additives.
- Make sure the water level in the water tank is between minimum level (indicated by "Min") and maximum level (indicated by "Max").
- Change the water in the tank frequently.


Place the unit on a firm level surface and plug it into a socket. The unit will emit a short "BIP" sound indicating that power is supplied and the indicator light (1) will be on on the control panel. For your convenience the unit can be operated by using control panel in the main body or by using remote control included.



Remote control


Buttons:

Indicator light:



Batteries

Remote control is supplied with battery inside (CR2025 type, 3V); remove the transparent sheet from the battery weak before use remote control. When the battery is weak, it must be replaced with the same type. To remove battery, follow the drawing on the back of remote control and on the following picture:



ON/OFF Button (A):

- Press On/Off button one time to activate the fan. The unit will show the ambient temperature in °C and will start to operate at minimum speed (indicator light 3 will be on in the control panel).
- Press On/Off button when unit is on to turn it off.

COOL Button (B):

- When unit is operating press cool button once to activate the evaporative cooling function. If this function is activated, the indicator light 2 will turn on in the control panel.
- **This function uses water so make sure about water level in the water tank before turn on this function.**

- To deactivate this function press again cool button. If the evaporative cooling function is deactivated the unit work as a fan.

SPEED Button (C):

- Press Speed button when unit is on to select the desired air speed: minimum (indicator light 3), medium (indicator light 4) or maximum (indicator light 5).

TIMER Button (D):

- When the unit is operating, you can set the timer to switch the fan off automatically after the set time. Press Timer button repeatedly to select the desired time period in one hour increment from 1 hours to 12 hours. The hours of settled timer are indicated on the display (indicator light 6). To deactivate timer function press this button till the indicator light (6) will show 00 or turn the fan off manually.

WIND MODES Button (E):

- When the unit is operating, you can select the desired wind mode: Normal mode (indicator light number 7 will be on in the display), Natural mode (indicator light number 8 will be on in the display) or Night mode (indicator light number 9 will be on in the display).

SWING Button (F):

- Press swing button when the unit is operating to activate the automatic left/right oscillation of vertical louvres. The "Swing" indicator light (10) will illuminate on the control panel. Press again swing button to deactivate the automatic swing.

IONIZER button (G):

- When unit is operating press ionizer button one time to activate ionizer function; the related indicator light (11) will turn on in the control panel.
- To deactivate ionizer function, press again this button.

5.Maintenance

Before carrying out routine cleaning, switch off the fan and disconnect mains power. For external cleaning use a soft and dry cloth.

DO NOT dip the device in water, or splash it with any other liquids.

DO NOT use solvents or any other chemical products for cleaning it.

When you do not use it, after cleaning it, store the fan in a dry place.

DAILY CLEANING: To reduce bacteria and scale residues, empty the water tank every day after use.

Cleaning the cooling pads:

When the cooling pads are dry, use a vacuum cleaner on the grids (4).

Cleaning of the water tank:

Fill the water tank with clean water.

On the bottom of the water tank there is a small plastic stopper (6) that can be removed. To completely empty the water tank place a container underneath the plastic stopper and gently remove the plastic stopper so that the water can drain out.

6.TECHNICAL SERVICE

Berton's Place #46 Sta. Rosa Street Barangay Manresa Quezon City

Tel Nos. 8442-3856; 8442-3866; 8282-5049, 8282-5098

Email: sales_mktg@colentco.com/iwata@colentco.com *Website: www.colentco.com