


Push-button soap dispenser

Specification



Tips:It is normal to have foam residue at the outlet, just wipe it.

- a:button
- b:USB port
- c:outlet
- d:charging light
- e:bottle
- f:inlet
- g:bottle connector
- h:USB cable


Warning:

- 1.Do NOT directly use liquid of emulsion type or frosted particle type.
- 2. Do NOT disassemble or sink the main unit .

Applicable Soap Type:

- 1.This product is suitable for foam hand sanitizer, foam makeup remover, cleansing foam, foam detergent.
- 2. liquid of emulsion soap or liquid of dishwashing foam can be diluted by clean water at 1: 5 by volume, and liquids shall be fully mixed and dissolved before use.

Power	5W	Voltage	4.2V
Material	ABS+silicone	Accessories	250ml bottle
Size	90*56*110mm		



Note:

1. The main unit can't be cleaned under water, as water in the main unit can cause a short circuit.
2. Just wipe the main unit with a damp cloth as routine cleaning with the charging port plugged with the water stopper.
3. Bottle and connectors can be disassembled and cleaned separately.
4. Pump some water and let it dry a bit before long time storage to avoid potential risk of foam residue in internal pipe/pump getting dry to cause a block

Functions:

1. Press button and hold for 2s' to turn on, and the product stands by for us for 12Hrs.
2. Put your hand below the outlet to have 8s' foaming and move away to stop.
2. Press button hold for 2s' to turn off for adding liquid or other purpose.
3. Led light will turn red during charging and turn green when charging done.