

User Manual

Thanks for choosing our mini Water Dispenser!

mini Water Dispenser AP138

Kit Include:

Unit *1
USB cord *1
Inlet Hose *1
User Manual *1



Attention

- 1. Please do NOT use this product to pump alcohol or other corrosive liquids such as oil or hot water over 40°C.
- 2. Please do NOT dip the product into water for cleaning.
- A small amount of water may come out from the unit prior to initial use and this is due to the quality control test done by factory using clean water to ensure it is functioning normally.

Specifications

Voltage: 5.0V DC Power: 4W

Battery: 1200 mAh Li-Ion

Installation







Operation

- 1. Please CHARGE to full capacity prior to initial use.
- 2. Indicator flashes red during charging, and remains red or turns off after charging done.
- 3. Press the button to start pumping and press again to stop.
- 4. During work, AP136FA has blue LEDs indicating water quality, while AP136FB has a bright LED bulb illuminates.

Maintenance & Storage

- 1. Silicone hose & SS spout can be boiled for a few minutes prior to initial use and after every 2 months for better hygiene.
- 2. It's suggested that Silicone Hose shall be replaced after 6 months use to avoid any potential hygiene issue.
- 3. Remove/dispense all excess water in the unit prior to storing unit for an extended time period.

Landlines.: 8282-5049; 8282-5098 Mobile Nos. 0908-8908597; 0917-3079188

Email: sales_mktg@colentco.com / iwata@colentco.com

Website: www.colentco.com

LEARN MORE

