




# iwata

## Electric Kettle




Model: CM16WK-A/CM16WK-B/  
CM16WK-C/CM16WK-D

Before using this kettle, please read this instruction manual completely.



Thank you for choosing Iwata. It is just one of a complete range of cleverly designed, safe and practical products which will help to make your life easier. Please read these instructions carefully to get the best results from this product.

## IDENTIFICATION OF PARTS



(Water level scale inside the kettle body)

## SAFETY INSTRUCTIONS

1. NO responsibility is accepted for damage resulting from improper use or non-compliance with the instructions.
2. The kettle is designed for heating water only. Never put any other liquid into the kettle, nor should it use another cooking appliance.
3. Before inserting the main plug into the socket check whether the supply line voltage and current rating are in compliance with the rated electric parameter shown on the kettle label.
4. Do not operate the kettle with wet hands.
5. Keep children away from the kettle which is either in heating or filled with hot water.
6. Please be careful to avoid scalding your skin with hot water or steam.
7. Discard the water in the kettle after boiling it for the first time prior to using it.
8. Do not touch any part of the kettle except the handle when the kettle is fully filled with boiling water.
9. Remove the plug from wall socket in the following cases:
  - a) after use
  - b) malfunction
  - c) before cleaning
10. When removing the plug from the wall socket never pull on the power cord.
11. Regularly clean and remove any build up of elements inside the kettle. Do not immerse the kettle and its base in water to avoid damaging the unit.
12. The appliance must not be immersed in water.
13. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
14. Children should be supervised to ensure that they do not play with the appliance.
15. If the supply cord is damaged, it must only be replaced by the manufacturer, distributor or its service agent.

## OPERATING GUIDELINES

### 1. Filling water

- The capacity of filled water is limited by the ultimate line graduated on the kettle body. It should not be higher than the max line, nor lower than the minimum line.
- On filling water, care should be taken to avoid water column flowing on the kettle's outside surface.

### 2. Locating

- Place the kettle on a stable flat surface.
- Never heat the kettle on any wet surface, do not allow water to penetrate the electrical parts inside the kettle
- Do not position the kettle on or near hot surface or near open flames.

### 3. Switching on

- Insert the main plug on the power cord into the wall socket.
- Please take care that the power cord must be well located and can't be caught on by a passerby
- Push the switch to activate.
- The red indicator lamp turns on to indicate that the kettle is starting to heat up.

### 4. Boiling

- The kettle will automatically switch off after a few seconds after the water boils.
- The red indicator lamp goes out as switch off.

### 5. Restoring

- After the kettle has switch off, it will need sometime to cool down. Almost after 15 seconds, the kettle can be switched on again by manual restoring.
- If the red indicator lamp still goes out after pushing the switch, it may be the case that the temperature sensing controller is still in hot condition and time must be taken for re-operating the kettle.

## FEATURES

- 1) Concealed heating element with stainless steel kettle bottom, resulting in convenience to clean.
- 2) Temperature sensing controller-automatic switch-off when water is boiling.
- 3) Dry boiling protector-boil-dry safety cutoff.
- 4) Easy-lift hinged lid.
- 5) Rotary (360) cordless base lead to the convenience for use.
- 6) Stainless steel body

## TECHNICAL DATA

MODEL NO	CM16WK-A	CM16WK-B	CM16WK-C	CM16WK-D
WATT	1500W	1500W	1500W	1500W
POWER	220V-240V/60Hz	220V-240V/60Hz	220V-240V/60Hz	220V-240V/60Hz
LITER	1.8L	1.8L	1.8L	1.8L

CMPI  
448-7674/442-3366  
WWW.COLENTCO.COM